

HotGate® Handle Kit

#340150



www.premier1supplies.com • 800-282-6631

How to install...

1. Remove net strings from top clips of the two endposts.
2. Slide a screwdriver into the clip, twist and lift from post.
3. Line up the bolt in the bottom of the handle with the hole in the top of the post. Thread handles onto posts.
4. Slip net strings into handle slots.
5. Clip handles together.



Plastic handles fit any NetPost 19 (0.75" dia) posts: PermaNet, QuikFence, ElectroFence or VersaNet Plus.

© Copyright 2016, Premier1Supplies. All rights reserved.