


# Assembly Instructions

## Poultry, Turkey & Game Crates



### TOOLS NEEDED



Dead Blow Hammer  
(#205015)  
or a rubber mallet.

### SPECIAL INSTRUCTIONS

Dry fit (**DO NOT** fully assemble)  
all components prior to  
snapping into place.

## Poultry Crate

#540202

### HOW TO ASSEMBLE

(**DO NOT** fully assemble until Step 6)



### WATCH VIDEO

Learn how to put  
crate together by  
scanning the QR code  
It's *very hard* to take apart the  
crate once put together!



SCAN ME




1. Partially insert the 2 door supports at the notched end of the crate base. Note: There's a flange on the edge of each door support **that should be faced towards the outside of the crate.**



2. Fit side panel to the inside of the door supports.



3. Set the rear panels in place. Make sure the extended side supports (flanges) face inward. The side supports go on the outside of the side plate (not the inside).



4. Set lid on top with the notched end going over the door supports.  
5. Check all panels and parts for fit by aligning all holes and pins.



6. Using a Dead Blow Hammer (#205015), mallet or hand strength. Starting at each corner, tap the components into place. Make sure the pins are all secured in their notches.



7. Door Assembly:  
a. Insert the spring and plunger (*inset*) into its receptacle on the hinged side of the door.  
b. Snap the plunger clip into place on the side of the crate that you would like as the hinge.  
c. Snap top and bottom door supports into place to complete the hinge.

# Turkey Crate

#540170



## WATCH VIDEO


Learn how to put crate together by scanning the QR code

It's *very hard* to take apart the crate once put together!



## HOW TO ASSEMBLE


(**DO NOT** fully assemble until Step 6)




1. Set the 2 door supports in place at the notched end of the crate base. Make sure the fully grooved side of the door supports face the inside of the crate.



2. Fit rear panel to the back of the crate. Make sure the grooved ends face the inside of the crate and that the smooth plastic "plate" faces out.



3. Set the side panels in place. Their "tongues" fit into the grooves of the door and rear supports. Make sure the smooth plate faces out.



4. Set lid on top with the notched end going over the door supports.
5. Check all panels and parts for fit by aligning all holes and pins.




6. Using a Dead Blow Hammer (#205015), mallet or hand strength, tap the components into place. Make sure the pins are all secured in their notches.



7. Door Assembly:
  - a. Insert the springs and plungers (*inset*) into the cups on the hinged side of the door.
  - b. Snap plungers into place on the side of the crate that you would like as the hinge.
  - c. Snap top and bottom door supports into place to complete the hinge.

# Game Crate

#540160



1. Install corner supports. A mallet (*see inset above*) may be needed for encouragement.



2. Doors can be placed on sides or ends. Make sure door pin fits into frame.



3. Set top onto crate. Align all holes and pins. Tap into place.



www.premier1supplies.com | 800-282-6631

© Copyright 2024, Premier1Supplies. All rights reserved.