

Heat Lamp (orange) Instructions

#557000

- 1) Insert desired bulb - maximum 250 watts. Both red and clear infrared bulbs can be used.
- 2) Close plastic mesh guard.

Note: To keep animals safe from the bulb, a strong and very secure plastic latch is used. This latch will require a tool unless the user has strong hands. Repeated use will make the task easier by flexing the plastic and learning the technique.

- a. Squeeze white plastic mesh together. (See photo 1.)
 - b. Place over orange latches.
 - c. Release finger pressure to secure guard. (See photo 2.)
- 3) Hang as required with a secure fastener. Select height to match the situation. The recommended minimum distance from the lamp to the ground or lamb/kid is 20".

To ensure safety, please self-inspect the plug and connection (or ask a certified electrician to do so.)



800-282-6631
www.premier1supplies.com

Washington, IA

© Copyright 2016, Premier1Supplies.
All rights reserved.



Photo 1



Photo 2